

HD-1 エクスパンジョン・サウンド - Vol. 1

PCMシンセシス・エンジンHD-1による、256個の新プログラムを追加します。往年の名曲に使われていた独特のビンテージ・エレピ、バンド演奏で際だつエッジの効いたピアノ、ブリティッシュ・ロックの名曲を喚起させるアップライト・ピアノ、定番のM1 Pianoや80年代によく使用されたきらびやかなステージ・ピアノなど、鍵盤楽器系音色を中心に、その他オルガン、ベル、ストリングス、ブラス、ウッドウィンドなどの即戦力となるプログラムを含みます。

◆注意◆

- ・ 256 個のプログラム・データは、2 つの PCG ファイルに分かれて収録されています。
- ・ いくつかのプログラムは、EXs1 のマルチサンプルを使用しています。EXs1 ROM Expansion がロードされていない場合は、正しく発音しません。これらのプログラムでは、プログラム・ネームの最後に EXs1 を含みます。

◆サウンド・データのロード方法◆

1. ダウンロードした.zip フォーマットの圧縮ファイルを解凍してください。
HD1_XP1.PCG ファイル、HD1_XP2.PCG ファイル、説明書が含まれます。
2. 2 つの PCG ファイルを、コンピュータに接続したハードディスクやフラッシュ・メモリー等の USB ストレージ・デバイスや ISO9660 CD-R/RW ディスクに書き込みます。
3. USB ストレージ・デバイスを、OASYS の USB 端子に接続します。CD の場合、OASYS の CD-R/RW ドライブにセットします。
4. USB ストレージ・デバイスの場合、Disk モード、Media Information ページのページ・メニュー・コマンド “ Scan device ” を、実行します。
5. 必要に応じて、Disk モード、Utility ページのページ・メニュー・コマンド “ Copy ” を使用して、USB デバイスや CD の PCG ファイルを、OASYS 内蔵ハードディスクにコピーして保存してください。
6. Disk モードで、OASYS インターナル・メモリーにロードします。
PCG ファイルには、以下のデータが含まれます。

HD1_XP1.PCG

・プログラム：USER-G バンク

HD1_XP2.PCG

・プログラム：USER-G バンク

それぞれの PCG ファイルをロードすると、プログラム・データが U-G バンクにロードされます。必要に応じて、任意のバンクにロードすることも可能です。

◆ロードの手順◆

1. [DISK]スイッチを押して Disk モードに入ります。
2. File タブ、Load タブを順番に押して、Disk モード、Load ページを選びます。
LCD 画面にファイル情報が表示されます。
3. “Drive Select” で USB デバイス、CD ドライブまたは内蔵ハードディスクを選びます。
4. HD1_XP1.PCG、または HD1_XP2.PCG ファイルを選びます。選んだファイルの表示が反転します。
5. Load ボタンを押すと、ダイアログが表示されます。
ページ・メニュー・コマンドの “Load selected” を選んでも同じダイアログが表示されます。
6. OK ボタンを押してロードを実行します。

◆任意のプログラム HD-1 バンクへロードの手順◆

1. 「ロードの手順」の 1 ～ 4 で、HD1_XP1.PCG ファイルを選びます。
2. Open ボタンを押します。Programs が表示されます。
3. Programs を選び、Open ボタンを押します。Bank U-G が表示されます。
4. Load ボタンを押すと、ダイアログが表示されます。
ページ・メニュー・コマンドの “Load selected” を選んでも同じダイアログが表示されます。
5. To: でロード先のバンクを選択します。
6. OK ボタンを押してロードを実行します。
7. 同様の方法で、HD1_XP2.PCG ファイルを OPEN して、Bank U-G データを任意のバンクにロードします。

List of Programs

HD1_XP1.PCG

Number	Program Name
G000	New Harmonic Grand Piano
G001	Natural Warm Grand
G002	Dark Warm Grand
G003	Dynamic Grand Piano
G004	Grand PF On Stage
G005	Grand PF mono On Stage
G006	Thin Bright Grand Piano
G007	Metallic Grand
G008	Stereo MIDI Grand w/Pad
G009	Piano Looper (SW1=Loop)
G010	LoFi Ac.Piano
G011	Upright Comp Piano
G012	Honky Tonk Piano
G013	CP Electric Grand
G014	CP-8080
G015	Pickup E.Grand Piano
G016	Piezo Piano & Pad SW1
G017	Electric Grand 2008
G018	M1 Grand PF On Stage
G019	M1 Piano
G020	M1 Piano w/Delay
G021	M1 & Pad
G022	AcGrand + E.Piano
G023	Ballad Piano Stack
G024	Cinematic Piano
G025	Piano/Guitar Pad
G026	Saloon Tack Piano
G027	Suit 73 E.Piano
G028	Direct E.Piano 1
G029	Master Rho.Piano 1
G030	Master Rho.Piano 2
G031	Suit E.Piano Keyoff
G032	Rubber Hammers E.Piano
G033	Silver Case E.Piano
G034	Phunky Drive E.Piano
G035	Suit E.P. Keyoff
G036	Stage E.P. Amp Type 1
G037	Stage E.P. Amp Type 2
G038	Stage E.P. Amp Type 3
G039	Stage E.P. Amp Type 4
G040	Suit E.P. Overdrive
G041	Powerful Suit E.P. SW1
G042	Pan Suit EP Knob5, SW1
G043	Wah Panning E.Piano
G044	Bright Stage E.Piano
G045	The Rho.Piano w/tremolo
G046	Ballad Suit E.P.
G047	Rich Tea E.Piano
G048	Bi-Phase E.Piano
G049	Phaser E.Piano
G050	Light Phaser E.Piano
G051	Dyno Comp E.Piano
G052	Dyno Chorus E.Piano
G053	Dyna-My Electric Piano
G054	Master Dyno E.Piano
G055	Pan Suit E.P. Pad 1 SW1
G056	Pan Suit E.P. Pad 2 SW1
G057	Dist Black Wurly
G058	Tremolo Oooly E.Piano
G059	Ghetto Tremolo Wurly
G060	Vintage Wurly Vibrato
G061	Tremolo Wurly
G062	Old 140A Wurly
G063	Pure Wurly E.Piano
G064	Master Wurly E.Piano

Number	Program Name
G065	Vintage Wurly Drive
G066	Advanced VPM E.P 1
G067	Advanced VPM E.P 2
G068	Advanced VPM E.P 3
G069	Advanced VPM E.P 4
G070	Advanced VPM E.P 5
G071	Deluxe E.Piano
G072	Bell Rose
G073	Warmmy E.Piano
G074	Formant VPM E.Piano
G075	Advanced DWGS E.Piano1
G076	Advanced DWGS E.Piano2
G077	Synthetic Piano
G078	Vintage Elektra Piano
G079	Ambient E.Piano
G080	Clav Keyoff 1
G081	Clav Keyoff 2
G082	Clav Keyoff 3
G083	Clav Knob 5,6
G084	Master Clav
G085	Touch Wah Clav
G086	Stereo Phase Clav
G087	Phase Clav keyoff
G088	Mute Clav Keyoff
G089	Syn Clav
G090	Clav w/Synth
G091	Harpsichord 1
G092	Harpsichord 2
G093	New Milford Castle Rbn
G094	Lounge Perc Organ
G095	Entertain. Organ SW1,2
G096	Perc Blues OD. Organ SW
G097	Old Movie Organ SW,Knob
G098	CX-3 Dark + Perc SW1,2
G099	888 + 3rdPerc Organ
G100	16"+ 5th Perc Organ
G101	Lounge Jazz Organ SW
G102	Master Perc Rock Organ
G103	Single Perc Organ
G104	Analog Org Pc.51/3 SW
G105	Master Full Organ
G106	Screamin' CX-3 SW1,2
G107	Old Rock CX-3 SW1,2
G108	Hard Rock Organ
G109	Perc. Rock CX-3 SW1,2
G110	Full Rock CX-3 SW1,2
G111	Master Perc Organ
G112	Tonewheel Leakage
G113	Rock Organ + DBars SW
G114	Master Rock Organ 1
G115	Master Rock Organ 2
G116	Master Rock Organ 3
G117	Master Rock Organ 4
G118	Basic Medium Organ SW
G119	Legendary CX-3 SW1,2
G120	Buckner Organ SW1,2
G121	The Big C
G122	Warm Comp. CX-3 SW, Knob
G123	Dark Blues OD. Organ
G124	CX-3 Registers SW1,2
G125	ToneWheel Left&Right
G126	Pale Shade Organ
G127	Ballade Organ SW1,2

HD1_XP2.PCG

Number	Program Name
G000	Jazzy Dark Organ SW,Knob
G001	J's Jazzy Organ
G002	Gospel CX-3 Var. SW1,2
G003	Jazzy Full Organ SW,Knob
G004	Old Cheesy Organ SW1,2
G005	Brit Entertain Org SW1,2
G006	Vox E.Organ 1
G007	Vox E.Organ 2
G008	Vox Organ Perc
G009	1966 Organ SW,Knob
G010	P5 Ribbon Organ
G011	Circus Organ
G012	Medium Chapel Organ
G013	Pipe Organ Mix
G014	Sweet Chapel Organ
G015	Chapel Organ Small/Med.
G016	Pipe Organ Positive Mix
G017	Full Reed Pipes SW,Knob
G018	French Big Pipe
G019	Pipe Organ Full
G020	Electronic Pipes SW,Knob
G021	DWGS Church Med. SW,Knob
G022	DWGS Church Full SW,Knob
G023	Velocity Bells
G024	Renaissance Celesta
G025	Simple Bells
G026	Brass Bells
G027	Ethnic Bell
G028	Glass Bells
G029	Bell Pad 1
G030	Bell Pad 2
G031	Twinkle Bell
G032	Organ Bell Pad
G033	Meditation Pedal, SW1
G034	Ambient Tubular Bell
G035	Bell Freq.
G036	Crystal Sine
G037	Clockshop Chimes
G038	Kalimbamba
G039	Ethnocentric
G040	Slamat malam
G041	String Duo
G042	Strings Marcato
G043	String Quartet
G044	Small String Section
G045	Multi Mode Strings
G046	Strings Vib Pad
G047	Dark Film String Section
G048	String Symphony
G049	St. Strings Marcato
G050	Brt Rosin Marcato Str.
G051	Strings Pad
G052	Wide Hall Strings
G053	Tremolandi Section EXs1
G054	Symphony Orchestra
G055	Analog Syn Strings
G056	Analog Strings Pad 1
G057	Analog Strings Pad 2
G058	Super Analog Strings
G059	Analog String Ens
G060	Progressive Ana Strings
G061	Tron Strings Ribbon
G062	Tron Cellos Ribbon EXs1
G063	Tron Strings Rbn EXs1
G064	Mellow Tron

Number	Program Name
G065	E. Cello > E. Violin
G066	Erhu SW1 EXs1
G067	Erhu Oct Duet SW1,2 EXs1
G068	Choral Pad
G069	Mix Scat
G070	Hoo Voices
G071	Voxy Lady
G072	Monastery Vox Pad EXs1
G073	Mongolian Voice EXs1
G074	Monks Legato JS EXs1
G075	Cathedral Vox Pad
G076	Dawn Chorus
G077	Tron Choir
G078	Meditation Pad
G079	Ribbon Airvox
G080	Spectrum Powder
G081	2 Trumpet Ens
G082	2 Trumpet Ens Octave
G083	2 Trumpets Oct-Velo Fall
G084	Sharp 2 Trumpets
G085	Bright Trumpet Section
G086	T.O.P Section
G087	Tp/Tb Section Vel Fall
G088	Tp/Tb Brass
G089	Tp/Tb Slow Legato
G090	Tp/Tb Octave Brass 1
G091	Tp/Tb Octave Brass 2
G092	Sharp Brass 1
G093	Sharp Brass 2
G094	Sharp Brass sfz
G095	Sharp Brass Velo Fall
G096	Pop Brass L/R
G097	Dyna Brass Section
G098	Brass Section 1
G099	Brass Section 2
G100	Brass Tp
G101	Hybrid Trombone Section
G102	Hybrid Trombones sfz
G103	Sax & Brass
G104	Pop Brass/Bari Sax
G105	Sharp Brass & Sax Octave
G106	Jazzy Tp & Sax
G107	Sharp Mute Tp/Tb
G108	Sharp Mute Tp/Tb Octave
G109	Sharp Mute Tp/Tb sfz
G110	Sharp 2 Mute Trumpets
G111	Nu French Horn Ensemble
G112	Nu Big Band Brass 5th
G113	Bright Piccolo Trumpet
G114	Dyna Trumpet
G115	Jazz Trumpet 1
G116	Jazz Trumpet 2
G117	Hybrid Trumpet sfz
G118	Flugelhorn Solo
G119	Hybrid Trombone
G120	Hybrid Trombone sfz
G121	Nu French Horn Solo
G122	Nu Tuba Solo
G123	New Vib Flute
G124	Jazzy Vib Flute
G125	Jazzy Flute Velo Flutter
G126	Jazz Flute Solo Perf.
G127	Flute Solo Perf.